



Roof Deck Tape™

MFM Building Products Corp. manufactures a wide range of innovative waterproofing products for the building industry. Proven through many years of use in the field, MFM products are engineered for superior performance and ease of installation.

DESCRIPTION

MFM Roof Deck Tape™ is a self-adhering tape composed of a non-slip film coated with a *BTS™* asphalt-based adhesive. The aggressive adhesive is protected by a disposable paper and self-seals around fasteners.

INTENDED USE

Use MFM Roof Deck Tape to tape all joints and seams of a roof deck, preventing water from entering the structure. Once the joints and seams are taped, the roof may be covered with roofing felt, synthetic or self-adhering underlayment. Should the main roof fail, Roof Deck Tape will prevent water from entering the structure between the roof deck panels.

The aggressive *Broad Temperature Spectrum™* asphalt-based adhesive used in Roof Deck Tape self-seals around roofing fasteners such as nails, screws and staples. Additionally, it readily sticks to plywood, OSB, rigid foam insulation, metal and other common roof deck materials.

Roof Deck Tape may also be used to prepare a substrate for Peel & Seal™ by taping wider than normal joint and seam gaps.

MFM Roof Deck Tape is the easy and economical way to prevent water from leaking into the building between the roof deck panels!

SPECIAL FEATURES

- Textured outer surface provides good traction when working on roofs.
- Self-seals around common roofing fasteners including nails and staples.
- Aggressively adheres – Roof Deck Tape sticks to plywood, OSB, foam board, metal, and most other roof deck materials for ease of application.



INSTALLATION

- Area to be taped must be clean and dry.
- Apply in dry weather at recommended temperatures.
- Apply Roof Deck Tape over the roof deck seams & joints.
- Peel back about 6" - 12" of the release paper, center tape over seam, adhere tape to roof deck and align.
- Continue to peel back the release paper as the tape is unrolled and press tape into place over roof seam.
- Allow 4" - 6" overlaps between pieces of tape. Overlaps must be made in a "shingle-like" manner so that water flows over the lap joint not against it.
- Apply firm, uniform pressure with a hand roller to the entire surface of the tape, especially at the overlaps.
- Cover with roofing underlayment within 60 days!
- Concrete, masonry, Densdeck®, Fiberock® and similar materials must be primed with an asphalt-based primer such as MFM Prime-A-Seal™ or MFM Spray Primer.
- Do not apply over uncured solvents, sealants, or silicone caulking! It is the installers responsibility to ensure that all sealants used are compatible with asphalt.

MFM Roof Deck Tape™ meets the requirements of ASTM D 1970-01

Recommended Application Range	35° F—110° F
Average Thickness	40 mils
Roll Length	66.7 ft
Roll Width	4", 6"
Linear Feet / Carton	4" = 600', 6" = 400'